

Macho Man Trunk Assembly



Remove the bolts from the rear of the unit using 12 mm socket. 2 on the top. 2 on the rear. 4 total.



The contents of the trunk are the black adapter plate, 2 brackets, the foam mat, the rubber mat, 4 long (thin) screws, 4 nuts, 4 washers, 4 short (wide) screws, 4 nuts



Attach the rear rack to the rear of the unit. Secure with the 4 bolts previously removed. Place the black adapter plate on top of the rack and insert the 4 long screws into the holes as seen in the picture.



Place the brackets over the screws on the underside of the rack. Secure using the washers and nuts.



Line up the holes in the trunk with the holes at the end of the plate closest to the backrest on the rack. Insert the 4 short screws and tighten using 12mm socket.

