



START / FLAMEOUT SWITCH

MAIN SWITCH

TURNING SWITCH

L				
OFF				
R				
0				
SR				

HORN SWITCH

ON		
OFF		
R/R/R		
B		

HIGH/LOW BEAM SWITCH

BRAKE SWITCH

ON		
OFF		
B		
Y/G		

COLOR INDICATION:

- RED-R, BLACK-B, BLUE-BL, PALE GREEN-PG
- WHITE-W, YELLOW-Y, GREEN-G, PURPLE-P
- BROWN-BR, GREY-GR, SKAY BLUE-SB
- ORANGE-O, DARK GREEN-DG
- SHORT CIRCUIT: